

### For non-touch screen Z-Line models **Z8 with AURA icons**

These steps have been provided as a guide for assistance with your Dejavoo non-touch screen payment device with AURA software.

**IMPORTANT:** The terminal's idle prompt displays **CREDIT** and **SALE** options and a prompt to access the **SERVICES** menu (**F1**). To change payment type, use the ↓ arrow key to select the payment type you prefer. To change transaction type, press the ← key until the transaction type you prefer appears.

#### CHIP CREDIT SALE

1. Input the **SALE AMOUNT** and press **OK**.
2. Tap (*contactless only*) or insert chip card.
3. If prompted, confirm the **SALE AMOUNT** by pressing **F2 (YES)** or **F4 (NO)**. *Conditional on the terminal's configuration.*
4. The transaction is processed. Sales receipts will print with details of the transaction.

#### MANUALLY ENTERED CREDIT SALE

1. Input the **SALE AMOUNT** and press **OK**.
2. Manually input card #.
3. Follow the CNP prompts (*input exp. date, ZIP code etc*). *Conditional on the terminal's configuration.*
4. The transaction is processed. Sales receipts will print with details of the transaction.

#### VOID CREDIT TRANSACTION (Card Present)

1. From your terminal home screen, press the ← key until **VOID** appears.
2. Input **VOID AMOUNT** and press **OK**.
3. Confirm void amount by pressing **F2 (YES)** or **F4 (CANCEL)**.
4. If prompted, input Manager Password (*1234 default*).
5. Tap (*contactless only*), insert, swipe or manually enter card #.
6. Confirm void amount by pressing **F2 (YES)** or **F4 (NO)**.
7. The transaction is processed. Void receipts will print with details of the transaction.

#### VOID CREDIT TRANSACTION (Card Not Present)

1. From the idle prompt, press **F1** to access the **SERVICES** menu.
2. Use the ↑ ↓ arrow keys to highlight **FAVORITES** and press **OK**.
3. Use the ↑ ↓ arrow keys to highlight **VOID CR/DB TRANS** and press **OK**.
4. Use the ↑ ↓ arrow keys to select **BY TRANSACTION #** and press **OK**.
5. Input **TRANSACTION #** to be voided and press **OK**.
6. If prompted, confirm the **VOID AMOUNT** by pressing **F2 (YES)** or **F4 (NO)**. *Conditional on the terminal's configuration.*
7. If prompted, input Manager Password (*1234 default*).
8. The void is processed. Void receipts will print with details of the transaction.

#### CREDIT CARD RETURN

1. From your terminal home screen, press the ← key until **RETURN** appears.
2. Input the **RETURN AMOUNT** and press **OK**.
3. Confirm the return amount by pressing **F2 (YES)** or **F4 (CANCEL)**.
4. If prompted input Manager Password (*1234 default*).
5. Tap (*contactless only*), insert, swipe or manually enter card #.
6. The transaction is processed. Return receipts will print with details of the transaction.


## REPRINT RECEIPT

1. From the idle prompt, press **F1** to access the **SERVICES** menu.
2. Use the ↑↓ arrow keys to highlight **FAVORITES** and press **OK**.
3. Use the ↑↓ arrow keys to highlight **REPRINT CR/DB RECEIPT** and press **OK**.
4. If prompted, input Manager Password (*1234 default*).
5. Use the ↑↓ arrow keys to highlight desired option (**LAST, BY TRANSACTION # or BY CARD NUMBER**) and press **OK**.
6. Transaction receipt prints.

## CALL ME FEATURE (Must Be Enabled)

1. From the terminal main screen press the **F4** key.
2. Use the ↑↓ arrow keys to highlight **CALL ME** and press **OK**.
3. The terminal sends notification to the help desk and you will receive a call back from a representative with assistance.

## TURN CLERK PROMPT ON/OFF

1. From the idle prompt, press **F1** to access the **SERVICES** menu.
2. Use the ↑↓ arrow keys to highlight **CORE** and press **OK**.
3. Use the ↑↓ arrow keys to highlight **APPLICATIONS** and press **OK**.
4. Use the ↑↓ arrow keys to highlight **CREDIT/DEBIT/EBT** and press **OK**.
5. Use the ↑↓ arrow keys to highlight **SETUP** and press **OK**.
6. If prompted, input Manager Password (*1234 default*).
7. Use the ↑↓ arrow keys to highlight **TRANS PROMPTS** and press **OK**.
8. Press **OK** to select **CLERKS**.
9. Press **OK** to select **PROMPT**.
10. Use the ↑↓ arrow keys to highlight desired option and press **OK**.
11. To return to the home screen press the  key 3 times.


## SETTLE DAILY BATCH

1. From the idle prompt, press **F1** to access the **SERVICES** menu.
2. Use the ↑↓ arrow keys to highlight **FAVORITES** and press **OK**.
3. Use the ↑↓ arrow keys to highlight **SETTLE DAILY BATCH** and press **OK**.
4. If prompted, input Manager Password (*1234 default*).
5. Terminal communicates with the host.
6. Settlement report prints.

## PRINTING REPORTS

1. From the idle prompt, press **F1** to access the **SERVICES** menu.
2. Use the ↑↓ arrow keys to highlight **FAVORITES** and press **OK**.
3. Use the ↑↓ arrow keys to highlight desired report type (**DAILY REPORT or SUMMARY REPORT**) and press **OK**.
4. If prompted, input Manager Password (*1234 default*).
5. **REPORT** prints.

## POWER CYCLE TERMINAL

1. Press and hold the  key on the keyboard and release once terminal starts to reboot.

## WI-FI ICON INDICATOR (for Wi-fi Enabled Units)



Wi-Fi connected successfully.